Kilo Graze/Wash (Kilo GW) - Installation Instructions

Models KGW-

Please read all instructions prior to installation and keep for future reference!


1. PRODUCT TO BE INSTALLED BY A QUALIFIED ELECTRICIAN.
2. USE ONLY WITH CLASS 2 POWER UNIT
3. 24 VOLTS DC
4. SUITABLE FOR DAMP LOCATIONS
5. UNDER-CABINET OR SURFACE MOUNT.
6. SUITABLE FOR INSTALLATION IN THE STORAGE AREA OF A CLOTHES CLOSET ON OUTPUTS 5.7W/FT OR LESS, NEC COMPLIANT FOR THE USA ONLY.
7. FIXTURE SHOULD BE INSTALLED BY TWO PEOPLE.

c UL us LISTED


REV0.8
04102026

luminii
7777 Merrimac Ave
Niles, IL 60714
T 224.333.6033
F 224.757.7557
info@luminii.com
www.luminii.com

1



1.1 Determine the location of the install. Use the pre-installed mounting bracket holes as a guide, then mark the desired location. If using adjustable mounting brackets, side screws must be loosen to rotate.




1.2 Align the mounting bracket holes to the marked locations on the surface, and secure by using the provided screws. If using the adjustable mounting brackets rotate to the desired position and tighten the side screws to secure. Make marks 4" from each end of the fixture(s) and also every 30" in between.

1.3 After the installation is complete remove the protective film from the front of the lens.

2


2.1 Follow one of the two options to connect the Kilo GW to the power supply

Option 1- Secure female quick connect to male quick connect. Feed male quick connect wire through conduit to power supply.



OR

Option 2- Feed wire whip to the power supply.



*LUMINII RESERVES THE RIGHTS TO CHANGE SPECIFICATION & INSTRUCTION WITHOUT NOTICE

Kilo Graze/Wash (Kilo GW) - Installation Instructions

Models KGW-

Please read all instructions prior to installation and keep for future reference!


1. PRODUCT TO BE INSTALLED BY A QUALIFIED ELECTRICIAN.
2. USE ONLY WITH CLASS 2 POWER UNIT
3. 24 VOLTS DC
4. SUITABLE FOR DAMP LOCATIONS
5. UNDER-CABINET OR SURFACE MOUNT.
6. SUITABLE FOR INSTALLATION IN THE STORAGE AREA OF A CLOTHES CLOSET ON OUTPUTS 5.7W/FT OR LESS, NEC COMPLIANT FOR THE USA ONLY.
7. FIXTURE SHOULD BE INSTALLED BY TWO PEOPLE.


c UL us LISTED


REV0.8
04102026

luminii
7777 Merrimac Ave
Niles, IL 60714
T 224.333.6033
F 224.757.7557
info@luminii.com
www.luminii.com

1 Kilo GW sample layout







*LUMINII RESERVES THE RIGHTS TO CHANGE SPECIFICATION & INSTRUCTION WITHOUT NOTICE

Please read all instructions prior to installation and keep for future reference!

1. PRODUCT TO BE INSTALLED BY A QUALIFIED ELECTRICIAN.
2. USE ONLY WITH CLASS 2 POWER UNIT
3. 24 VOLTS DC
4. SUITABLE FOR DAMP LOCATIONS
5. UNDER-CABINET OR SURFACE MOUNT.
6. SUITABLE FOR INSTALLATION IN THE STORAGE AREA OF A CLOTHES CLOSET ON OUTPUTS 5.7W/FT OR LESS, NEC COMPLIANT FOR THE USA ONLY.
7. FIXTURE SHOULD BE INSTALLED BY TWO PEOPLE.

luminii
7777 Merrimac Ave
Niles, IL 60714
T 224.333.6033
F 224.757.7557
info@luminii.com
www.luminii.com

Power Supply Wiring Diagram

Note: *Prior to installation all 24VDC wires must be present near fixture. Refer to the power supply installation instructions for additional information.*

Static White
Wiring Diagram PDF

RGB/RGBW
Wiring Diagram PDF

Warm Dim
Wiring Diagram PDF

Pixel
Wiring Diagram PDF

Tunable White
Wiring Diagram PDF

Kilo Graze/Wash (Kilo GW) - Installation Instructions

Models KGW-

Please read all instructions prior to installation and keep for future reference!

1. PRODUCT TO BE INSTALLED BY A QUALIFIED ELECTRICIAN.
2. USE ONLY WITH CLASS 2 POWER UNIT
3. 24 VOLTS DC
4. SUITABLE FOR DAMP LOCATIONS
5. UNDER-CABINET OR SURFACE MOUNT.
6. SUITABLE FOR INSTALLATION IN THE STORAGE AREA OF A CLOTHES CLOSET ON OUTPUTS 5.7W/FT OR LESS, NEC COMPLIANT FOR THE USA ONLY.
7. FIXTURE SHOULD BE INSTALLED BY TWO PEOPLE.


c UL us LISTED

REV0.8
04102026


luminii
7777 Merrimac Ave
Niles, IL 60714
T 224.333.6033
F 224.757.7557
info@luminii.com
www.luminii.com

Multiple powerfeed layouts


power supplies at the end of the run



power supplies in the middle of the run



consecutive layout, NOT RECOMMENDED



*LUMINII RESERVES THE RIGHTS TO CHANGE SPECIFICATION & INSTRUCTION WITHOUT NOTICE